

# SL 12,000 FP Specifications

4 Post Lift: SL 12,000 FP  
INSTALLATION manual



**WARNING:** If ANCHORING Post (optional) to floor, square up all measurements and wait till your Lift is assembled in it's entirety. Once fully assembled, then anchor Post to floor.




FIGURE 1 (Vehicle Lift Specifications Drawing)

We reserve the right to make changes in specifications without notice and without making changes retroactive.



**WARNING:** If ANCHORING Post (optional) to floor, square up all measurements and wait until your Lift is assembled in its entirety. Once fully assembled, then anchor Post to floor.




FIGURE 2 (Vehicle Lift Layout Drawing)

**Note for Figure 2 -** We recommend 12" (INCHES) between the post and the nearest wall.

We reserve the right to make changes in specifications without notice and without making changes retroactive.